





Electrolux

Instruction Book

600 CORDLESS CLEANER











*
 Accessories may vary from model to model. | Les accessoires peuvent varier d'un modèle à l'autre. | Ausstattung und Zubehör kann je nach Modell variieren. | Accessoires kunnen per model verschillen. | Tillbehören kan variera mellan olika modeller. | Lisävarusteet voivat vaihdella malleittain. | Tilbehør kan variere fra modell til modell. | Tilbehør kan variere fra modell til modell. | Los accesorios pueden variar según el modelo. | Os acessórios podem variar de modelo para modelo. | Gli accessori possono variare da modello a modello. | Τα εξαρτήματα ίσως διαφέρουν από μοντέλο σε μοντέλο. | Lisad võivad mudelist mudelisse varieeruda. | Priedai kitiems modeliams gali skirtis. | Akcesoria mogą się różnić w zależności od modelu. | Piederumi katram modelim var atšķirties. | Příslušenství se může u jednotlivých modelů lišit. | Doplnky sa môžu líšiť v závislosti od modelu. | Dodaci se mogu razlikovati kod određenih modela. | Nastavki se lahko glede na model razlikujejo. | Принадлежности могут отличаться от модели к модели. | Ці компоненти можуть відрізнятися залежно від моделі. | tartozékok típusonként eltérőek lehetnek. | Accesorile pot diferi de la model la model. | Принадлежностите може да се различават според различните модели. | Aksesuarlar, modelden modele farklılık gösterebilir. | رخآل لیڊوم نم فلټخت دقتا قفرملا. | Додаци могу да се разликују у зависности од модела усисивача. | อุปกรณ์เสริมอาจแตกต่างกัน ในแต่ละรุ่น
 仅特定机型提供 | 약세사리는 모델마다 다를 수 있습니다. |
 Els accessoris poden canviar segons el model














Carpet


















Hard Floor





















 www.shop.electrolux.com



| | | | | | | |
|---|---|---|---|---------------------------------------|---|---|
| ESKW6 900 923 742 Yearly Performance Kit | KIT23 900 923 383 Home and Car Kit | KIT22 900 923 354 Duster Kit | ZE186 900 923 768 Extra Battery 2.5Ah/54Wh | ZE182 900 923 764 PetPro | EPPCS2 900 923 550 PowerPro Cleaning Station | ZE156 900 923 369 PowerPro Hard Floor Nozzle |
|---|---|---|---|---------------------------------------|---|---|



| | | | | |
|--|--|--|---------------------------------------|--|
| ZE187 900 923 769 PowerPro Mop Nozzle | ZE158 900 923 440 Standard Pads | ZE159 900 923 442 Delicate Pads | ZE146 900 923 361 Duster | ZE188 900 923 770 Floor Stand |
|--|--|--|---------------------------------------|--|



A27940401